

Section IV

Normal Procedures

1. Normal Operating procedures are addressed in the AEC Electronic Checklist "User & Installation manual", which is provided with each installation. It is the aircraft's operator responsibility to ensure the AEC Checklist is current with the current information from the aircraft's appropriate AFM or POH and be familiar with its operation before take-off. The current FAA Approved AFM & POH must be available to the operator for all aircraft operations.

Section V

Performance

1. No change.

Section VI

Weight & Balance

1. Review Weight & Balance Report.

FAA APPROVED
DEC 18 2009
Date _____ Initials _____